Preval Troubleshooting Tips

- Once you have filled the jar with DuraCoat and attached the power unit, do not shake the Preval Sprayer. There is a vent hole in the bottom of the power unit and DuraCoat may leak out. Also, do not tilt the Preval more than 45 degrees as this can cause DuraCoat to leak out of the vent hole

- Depress the spray button and make even passes across all parts. If a rough, pebbly finish is the result, move the Preval Sprayer a little closer to the parts when making passes. Also, slow down the speed of the pass across the parts attempting to deposit more DuraCoat on the parts. Make sure to wait 5 minutes between coats. The desired result for the second and third coats is to achieve wet coats.

- If runs or drips occur, the Preval Sprayer is too close to the parts. To remedy this, back off on the distance the Preval Sprayer is from the parts. Also, try to increase the speed of the passes across the parts.

- Once the DuraCoat and Hardener are mixed together, you have approximately 6-8 hours to use it. It will not be useable the next day.

- If you only want to mix ½ of the DuraCoat and Hardener and intend to use the rest later in your Preval Sprayer, you will need to clean out the sprayer with DuraCoat Reducer. If the Preval Sprayer is not cleaned out, the DuraCoat will harden in the spray head making the sprayer unusable.

Preval Troubleshooting Tips

- Once you have filled the jar with DuraCoat and attached the power unit, do not shake the Preval Sprayer. There is a vent hole in the bottom of the power unit and DuraCoat may leak out. Also, do not tilt the Preval more than 45 degrees as this can cause DuraCoat to leak out of the vent hole

- Depress the spray button and make even passes across all parts. If a rough, pebbly finish is the result, move the Preval Sprayer a little closer to the parts when making passes. Also, slow down the speed of the pass across the parts attempting to deposit more DuraCoat on the parts. Make sure to wait 5 minutes between coats. The desired result for the second and third coats is to achieve wet coats.

- If runs or drips occur, the Preval Sprayer is too close to the parts. To remedy this, back off on the distance the Preval Sprayer is from the parts. Also, try to increase the speed of the passes across the parts.

- Once the DuraCoat and Hardener are mixed together, you have approximately 6-8 hours to use it. It will not be useable the next day.

- If you only want to mix ½ of the DuraCoat and Hardener and intend to use the rest later in your Preval Sprayer, you will need to clean out the sprayer with DuraCoat Reducer. If the Preval Sprayer is not cleaned out, the DuraCoat will harden in the spray head making the sprayer unusable.

Preval Troubleshooting Tips

- Once you have filled the jar with DuraCoat and attached the power unit, do not shake the Preval Sprayer. There is a vent hole in the bottom of the power unit and DuraCoat may leak out. Also, do not tilt the Preval more than 45 degrees as this can cause DuraCoat to leak out of the vent hole

- Depress the spray button and make even passes across all parts. If a rough, pebbly finish is the result, move the Preval Sprayer a little closer to the parts when making passes. Also, slow down the speed of the pass across the parts attempting to deposit more DuraCoat on the parts. Make sure to wait 5 minutes between coats. The desired result for the second and third coats is to achieve wet coats.

- If runs or drips occur, the Preval Sprayer is too close to the parts. To remedy this, back off on the distance the Preval Sprayer is from the parts. Also, try to increase the speed of the passes across the parts.

- Once the DuraCoat and Hardener are mixed together, you have approximately 6-8 hours to use it. It will not be useable the next day.

- If you only want to mix ½ of the DuraCoat and Hardener and intend to use the rest later in your Preval Sprayer, you will need to clean out the sprayer with DuraCoat Reducer. If the Preval Sprayer is not cleaned out, the DuraCoat will harden in the spray head making the sprayer unusable.