# DuraCoat® Instructions (Simplified)

**For In-Depth Instructions visit the DuraCoat® Learning Center at www.lauerweaponry.com**

1. **Disassemble the firearm**
2. **Degrease using LCW TruStrip**
3. **Rough up the surface by sanding with 400-600 grit sandpaper or by sandblasting with sand or aluminum oxide – This is especially important when coating plastic or synthetic parts. Skip this step if you are coating over Parkerizing.**
4. **Shake DuraCoat for 3 minutes AFTER hearing the mixing ball.**
5. **Mix DuraCoat and DuraCoat Hardener at a ratio of 12:1. Thinning should only be done if needed and only with DuraCoat Reducer.**
6. **Apply DuraCoat in 3-4 thin even layers. Allow at least 10 minutes in between layers. Hold sprayer 4-8" away from surface.**
7. **If using stencils, wait at least 3 hours before applying and before removing.**
8. **Clean up using DuraCoat Reducer.**
9. **DuraCoat will dry to the touch in 20 minutes. Reassembly and light use can be done after 24 hours. Full cure is reached in 3-4 weeks. Do not put through rough use or holster until fully cured.**

# Instructions pour DuraCoat® (simplifiées)

**Pour des instructions complètes, visitez le centre d'apprentissage DuraCoat® à www.lauerweaponry.com**

1. **Désassembler l'arme à feu**
2. **Dégraisser en utilisant LCW TruStrip**
3. **Marquer la surface en sablant avec du papier sablé à grain 400-600 ou en sablant au jet ou à l'oxyde d'aluminium – ceci est particulièrement important pour le revêtement du plastique ou de pièces synthétiques. Sauter cette étape si vous appliquez un revêtement sur du Parkerizing.**
4. **Agiter le DuraCoat pendant 3 minutes APRÈS avoir entendu la bille de mélange.**
5. **Mélanger le DuraCoat et le DuraCoat Hardener à un ratio de 12:1. Une dilution ne doit être faite que si nécessaire et seulement avec le DuraCoat Reducer.**
6. **Appliquer le DuraCoat en 3-4 couches minces uniformes. Attendre au moins 10 minutes entre les couches. Tenir le vaporisateur à une distance de 4 à 8 po de la surface.**
7. **Si vous utilisez un pochoir, attendre au moins 3 heures avant l'application et avant de le retirer.**
8. **Nettoyer en utilisant le DuraCoat Reducer.**
9. **DuraCoat sera sec au toucher en 20 minutes. L'assemblage et une utilisation légère peuvent être faits après 24 heures. Le séchage complet est atteint en 3 à 4 semaines. Ne pas utiliser de façon intensive ni placer dans un étui à pistolet avant que le produit ne soit complètement sec.**