DuraDrab™

Lustreless Olive Drab
WWII Vehicle Paint

Application Instructions

1. Disassemble parts as far as you feel comfortable.
2. Degrease parts with LCW TruStrip™ Cleaner/Degreaser. A 3M Scotchbrite pad is recommended to help with removing all the oils. Make sure to remove any existing rust or corrosion.
3. Sanding or sandblasting are optional but will increase the durability of the DuraDrab™. Sand by hand with 400 grit sandpaper or sandblast with 120 grit aluminum oxide for best results.
4. Mask any areas off that you do not want to coat.
5. Shake the DuraDrab™ for three minutes after hearing the mixing ball. Mix 12 parts DuraDrab™ with one part DuraCoat® Hardener. For example: This can be measured as 4 tablespoons DuraDrab™ to one teaspoon Hardener. This mixture has a pot life of 6-8 hours.
6. Apply in 3-4 thin, wet layers. Allow to dry at least 10 minutes in between layers.
7. Once fully coated:
    a. Hang parts to dry overnight. Reassembly can be done the next day and item can be put into use.

    OR

    b. Bake metal parts at 110°F for 90 minutes or 200°F for 20 minutes. Reassembly can be done and item put into use once parts have cooled down to room temperature.

NOTE: Only expose your parts to light use during the 3-4 week cure time. Once fully cured, DuraDrab™ will provide an abrasion, impact, and corrosion resistant finish. It will also be resistant to oils, cleaners, and solvents including gasoline.

ATTENTION: Always wear protective gloves, eyewear, and an approved respirator. Be in a well-ventilated area. Read all warnings and first aid information, and read and follow all instructions when using any DuraCoat® products.

Call us at 800-830-6677 with any issues or questions.