DuraCoat® EasyWay™ Camo Kit Instructions

1. Prep your metal, plastic, or wood parts by spraying the TruStrip™ Cleaner/Degreaser causing the oil and grime to run off. Then scuff with the enclosed pad.

2. Shake the DuraCoat® bottle for three minutes then pour into the glass jar. Add 1/4 of the bottle of DuraCoat® Hardener. Screw white cap onto the jar and shake for one minute. Remove the cap and screw on the Preval sprayer.

3. Apply the base color to the entire firearm. Spray your parts in thin, even passes. Allow the part to dry for 5 minutes in between coats. Apply approximately three coats. Clean jar and Preval using the enclosed DuraCoat® Reducer. Wipe jar clean and spray Reducer through the Preval until it runs clean. Allow the parts to dry for 2-3 hours before applying stencils.

4. Mix the next color and 1/4 of the bottle of Hardener in the jar, reattach the Preval Sprayer. Using the enclosed stencils, apply the second color. Allow the parts to dry for 2-3 hours before moving on to the next color. Clean the jar and Preval again. Follow these steps for the third and fourth colors.

5. Hang your parts to dry. Allow to dry overnight before reassembly. Make sure to complete the entire project within 7 days. Only expose the parts to light use during the 3-4 week cure time. Once fully cured, your parts will not scratch or chip and will be resistant to all solvents and cleaners.

More detailed instructions are available on the DuraCoat Firearm Finishes YouTube channel.

NOTE: Always wear protective gloves, eyewear, and an approved respirator. Be in a well-ventilated area. Read all warnings and first aid information, and read and follow all instructions when using any DuraCoat® products.