Girl's Guide to Guns.com
DuraCoat® Finishing Kit Instructions

1) Prep your metal, plastic or wood parts by spraying the TruStrip™ Cleaner/Degreaser causing the oil and grime to run off. Then scuff with the enclosed pad keeping the pad saturated with TruStrip.
2) Shake the DuraCoat® bottle for three minutes after hearing the mixing ball then pour the entire contents into the glass jar. Add the entire contents of the enclosed DuraCoat® Hardener. Screw the white cap onto the jar and shake for one minute. Remove the cap and screw on the Preval sprayer.
3) Spray your parts in thin, even passes. Allow the part to dry for 5 minutes in between coats. Apply approximately three coats.
4) Hang your parts to dry for at least 30 minutes but no more than seven days.
5) Empty any remaining contents of the Preval jar. Clean out the Preval Sprayer using the DuraCoat® Reducer. Pour the entire bottle of Reducer into the jar and spray until clear.
6) Shake the DuraPearl™ bottle for three minutes then pour the entire contents into the glass jar. Add DuraPearl™ Hardener. Screw the white cap onto the jar and shake for one minute. Remove the cap and screw on the Preval sprayer.
7) Spray your parts in thin, even passes. Allow the part to dry for at least 5 minutes in between coats. Apply as much or as little as desired but do not exceed three coats.
8) Hang your parts to dry. It may take longer for the DuraPearl™ to dry than the DuraCoat®. This is normal.
9) Allow to dry at least overnight before assembly. Allowing your parts to dry longer is better. Only expose the parts to light use during the 3-4 week cure time. Once fully cured, your parts will not scratch or chip and will be resistant to all solvents and cleaners.

Always wear protective gloves, eyewear, and an approved respirator. Be in a well-ventilated area. Read all warnings and first aid information, and read and follow all instructions when using any DuraCoat® products.