# Quicken™ Instructions

**WARNING: Read these instructions in their entirety before mixing or using Quicken! Failure to follow these instructions may result in damage to your spray equipment.**

Quicken is designed to accelerate the "*initial cure*" and "*final cure*" of DuraCoat, DuraMetl, DuraLaser, DuraBrite, DuraPearl and DuraVelvet. Quicken can be used to accelerate the cure to most any time frame thus adapting the DuraCoat to specific production and shipping requirements. The DuraCoat to Quicken ratio maximum is 8 parts catalyzed DuraCoat to 1 part Quicken. The more Quicken that is added to DuraCoat the faster the cure time. Conversely, the less Quicken that is added to DuraCoat the slower the cure time. The ratio and resulting cure time will vary with temperature, humidity, elevation, proximity to sea coasts, longitude, application technique, etc. Thus the end user must experiment to find the optimum ratio for the desired results at a given location. *Be very cautious*. Adding Quicken to DuraCoat not only shortens the cure time, it also shortens the "*pot life*". Pot life is the length of time that DuraCoat can safely exist in spray equipment. The pot life on DuraCoat is 6-8 hours. At the end of this time frame the DuraCoat will begin to thicken and will eventually become rock hard thus destroying the spray equipment. The more Quicken that is added to DuraCoat the shorter the pot life. In simpler words, don't mix a batch of DuraCoat and Quicken and then go to lunch.

# Instructions d'utilisation de Quicken[MC]

**AVERTISSEMENT : Lisez ces instructions au complet avant de mélanger ou d'utiliser Quicken! Le non-respect de ces instructions pourrait endommager votre équipement de vaporisation.**

Quicken est conçu pour accélérer le « *séchage initial* » et le « *séchage final* » de DuraCoat, DuraMetl, DuraLaser, DuraBrite, DuraPearl et DuraVelvet.
Quicken peut être utilisé pour obtenir n'importe quel temps de séchage de DuraCoat pour répondre aux exigences de production et d'expédition. Le ratio DuraCoat/Quicken maximum est de 8 mesures de DuraCoat catalysé par mesure de Quicken. Plus vous ajoutez de Quicken à DuraCoat, plus le temps de séchage est rapide. De même, moins vous ajoutez de Quicken, moins le temps de séchage sera rapide. Le ratio et le temps de séchage requis varieront selon la température, l'humidité, l'altitude, la proximité des côtes maritimes, la longitude, la technique d'application, etc. L'utilisateur doit donc faire des tests pour trouver le ratio optimum selon les résultats désirés dans un endroit donné. *Faites également très attention*. L'ajout de Quicken à DuraCoat réduit non seulement le temps de séchage, mais également la « *durée d'utilisation* ». La durée d'utilisation est le temps que DuraCoat peut être conservé sans danger dans l'équipement de vaporisation. La durée d'utilisation de DuraCoat est de 6 à 8 heures. À la fin de cette période, DuraCoat commencera à épaissir et deviendra éventuellement solide ce qui endommagera l'équipement de vaporisation. Plus vous ajoutez de Quicken à DuraCoat, plus la durée d'utilisation est courte. En d'autres mots, ne faites pas un mélange de DuraCoat et de Quicken juste avant la pause du dîner.