DuraCoat® Shake ‘N Spray Finishing Kit Instructions

1) Prep your metal, plastic or wood parts by spraying the TruStrip™ Cleaner/Degreaser causing the oil and grime to run off. Then scuff with the enclosed pad keeping the pad saturated with TruStrip.
2) Shake the DuraCoat® bottle for three minutes then pour the entire contents into the glass jar. Add the entire contents of the enclosed DuraCoat® Hardener. Screw the white cap onto the jar and shake for one minute. Remove the cap and screw on the Preval sprayer.
3) Spray your parts in thin, even passes. Allow the part to dry for 5 minutes in between coats. Apply approximately three coats.
4) Hang your parts to dry. Allow to dry overnight before assembly. Only expose the parts to light use during the 3-4 week cure time. Once fully cured, your parts will not scratch or chip and will be resistant to all solvents and cleaners.

DuraCoat® Shake ‘N Spray Finishing Kit Instructions

1) Prep your metal, plastic or wood parts by spraying the TruStrip™ Cleaner/Degreaser causing the oil and grime to run off. Then scuff with the enclosed pad keeping the pad saturated with TruStrip.
2) Shake the DuraCoat® bottle for three minutes then pour the entire contents into the glass jar. Add the entire contents of the enclosed DuraCoat® Hardener. Screw the white cap onto the jar and shake for one minute. Remove the cap and screw on the Preval sprayer.
3) Spray your parts in thin, even passes. Allow the part to dry for 5 minutes in between coats. Apply approximately three coats.
4) Hang your parts to dry. Allow to dry overnight before assembly. Only expose the parts to light use during the 3-4 week cure time. Once fully cured, your parts will not scratch or chip and will be resistant to all solvents and cleaners.